



PORTABLE AND REMOTE CONDENSER CHILLERS Model NQ

INSTRUCTION MANUAL



November 2016
IMS Company
10373 Stafford Road
Chagrin Falls, OH 44023-5296

Telephone: (440) 543-1615
Fax: (440) 543-1069
Email: sales@imscompany.com
Website: www.imscompany.com

Page Intentionally Blank

Table of Contents

Foreword	1
Safety Guidelines	2
Installation	2
Receiving Inspection	2
Rigging, Handling, and Locating Equipment	3
Foundation.....	3
Electrical Power	3
Condenser Water Lines (NQW Models Only)	4
Table 1 – Water Cooled Condenser Water Flow Rate Requirements.....	5
Figure 1 – Condenser Water Pressure Drop Curves (NQW05 through NQW15).....	6
Figure 2 – Condenser Water Pressure Drop Curves (NQW20 through NQW40).....	7
Air-Cooled Chillers Condenser Air	8
Chilled Water Lines	8
Figure 3 – Recommended Overhead Piping.....	9
Table 2 – Chiller Flow Rate Limitations	10
Figure 4 – Standard Flow Unit Coolant Pressure Drop Curve (NQ4 and NQ5)	11
Figure 5 – High Flow Unit Coolant Pressure Drop Curve (NQ04 and NQ05)	12
Figure 6 – Standard Flow Unit Coolant Pressure Drop Curve (NQ8 through NQ15)	13
Figure 7 – High Flow Unit Coolant Pressure Drop Curve (NQ08 through NQ15).....	14
Figure 8 – Standard Flow Unit Coolant Pressure Drop Curve (NQ20 through NQ40)	15
Figure 9 – High Flow Unit Coolant Pressure Drop Curves (NQ20 through NQ40)	16
Figure 10 – NQ Series Pump Curves.....	17
System Fluid Freeze Protection	18
Interconnecting Refrigerant Piping (NQR Models Only)	18
Operating Principles	19
Coolant Circuit	19
Refrigerant Circuit.....	19
Start-Up	20
Table 3 - Recommended Glycol Solutions.....	21
Microprocessor Controller Operation	23
Start Button	24
Stop Button	24
Alarm Silence / Alarm Reset Button	24
Compressor Running Hours Button	24
Pump Running Hours Button	25
Pump Test Button	25
Display/Program Button	25
Up Button.....	25
Down Button.....	26

Control Power On LED	26
Autostart Signal LED	26
Pump LED	26
Hot Gas Bypass LED.....	26
Compressor #1 LED	27
Compressor #2 LED	27
Temperature Limit LED	27
Electrical Phase Error LED	28
Low Flow LED	28
Freezestat LED	28
Low Reservoir Level LED	28
Compressor Recycle LED.....	28
High Refrigerant Pressure LED.....	28
Low Refrigerant Pressure LED.....	29
Program Mode LED	29
Set Point Temperature Display	29
Process Temperature Display	29
Program Menu	29
Table 4 - Controller Program Menu	31
Table 5 – Controller Control Fault Logic.....	32
Table 6 – ModBus Option Parameters (Integer Values)	33
Table 7 – ModBus Option Parameters (Floating Point Values).....	34
PLC Controller Navigation.....	36
Start-Up Screen & Contact Information	36
Main Screen	36
Refrigeration Diagnostic Screen	38
Process Diagnostic Screen	39
Active Alarms Screen / Alarm History.....	40
Output Status / Output Designation.....	42
Setup Screens.....	43
Compressor Setup	43
Temperature Alarm Settings	43
Freezestat Setup.....	43
Hot Gas Bypass PID.....	43
Components	44
Chilled Water Return Temperature Sensor	44
Chilled Water Supply Temperature Sensor	44
Compressor	44
Compressor Electronic Motor Module	44
Condenser Remote Air-Cooled (NQR Models Only)	45
Condenser Integrated Air-Cooled (NQA Models Only)	45
Fan Cycling Controls (NQA Models Only)	45
Condenser Water-Cooled (NQW Models Only).....	45

Condenser Water Regulating Valve (NQQ Models Only)	45
Coolant Flow Switch	46
Crankcase Heater	46
Evaporator	46
Hot Gas Bypass Valve.....	46
High Refrigerant Pressure Switch	46
Low Refrigerant Pressure Switch.....	46
Human Machine Interface (HMI).....	47
Pressure Relief Valve	47
Receiver	47
Refrigerant Filter/Drier	47
Refrigerant Service Valve.....	47
Refrigerant Sight Glass.....	47
Y-Strainer	48
Automatic Water Make-Up (Optional)	48
Coolant Pump	48
Upgraded Pumps (Optional)	48
Pressure Gauge	48
Reservoir	48
Preventive Maintenance	50
Once a Week	50
Once a Month	51
Every Three Months.....	51
Preventive Maintenance Checklist.....	52
Troubleshooting	53
Drawings	54

Page Intentionally Blank

Foreword

The intent of this manual is to serve as a guide for placing your portable chiller in service and operating and maintaining it properly. Improper installation can lead to poor equipment performance or severe equipment damage. Failure to follow the installation instructions may result in damage not covered by your warranty. It is extremely important that a qualified refrigeration installation contractor perform all installation line sizing and piping. Please supply these instructions to your authorized refrigeration contractor. This manual is for our standard product line with supplements as required to accommodate any special items provided for a specific application. The written information contained in this manual, as well as various drawings, are intended to be general in nature. The drawings included in this manual are typical only and may not represent the actual unit purchased. Actual drawings are included with the equipment for troubleshooting and servicing of the unit. Additional copies of drawings are available upon request. We strive to maintain an accurate record of all equipment during the course of its useful life. Every effort was made to standardize the design features of these chillers, the various options may make it necessary to rearrange some of the components; therefore, some of the general drawings in this manual may differ from your specific unit.

Due to the ever-changing nature of applicable codes, ordinances, and other local laws pertaining to the use and operation of this equipment we do not reference them in this manual. There is no substitute for common sense and good operating practices when placing any mechanical equipment into operation. We encourage all personnel to familiarize themselves with this manual's contents. Failure to do so may unnecessarily prolong equipment down time.

The chilling equipment uses chemical refrigerants for heat transfer purposes. This chemical is sealed and tested in a pressurized system containing ASME coded vessels; however, a system failure will release it. Refrigerant gas can cause toxic fumes if exposed to fire. Place these units in a well-ventilated area, especially if open flames are present.

Failure to follow these instructions could result in a hazardous condition. The standard refrigerant used in these units is a hydro fluorocarbon (HFC) trade named R-410A. We strongly recommend our customers implement a refrigerant management program including a survey of all equipment to document the type and quantity of refrigerant in each machine. We recommend all refrigeration service technicians be licensed and certified by an EPA approved organization. Follow good piping practices and the information in this manual to ensure a successful installation and operation of this equipment. We are not responsible for liabilities created by substandard piping methods and installation practices external to the chiller.

We trust your equipment will have a long and useful life. If you should have any questions, please contact our Customer Service Department specifying the serial number and model number of the unit as indicated on the nameplate.

Safety Guidelines

Observe all safety precautions during installation, start-up, and service of this equipment due to the presence of high voltage and refrigerant charge. Only qualified personnel should install, start-up, and service this equipment.

When working on this equipment, observe precautions in literature, and on tags, stickers, and labels located on the equipment. Wear work gloves and safety glasses.



WARNING: *This equipment contains hazardous voltages that can cause severe injury or death. Disconnect and lock out incoming power before installing or servicing the equipment.*



WARNING: *This equipment contains refrigerant under pressure. Accidental release of refrigerant under pressure can cause personal injury and or property damage. Exercise care while working on or around this equipment.*



WARNING: *Vent all refrigerant relief valves in accordance to ANSI/ASHRAE Standard 15, Safety Code for Mechanical Refrigeration. This equipment should be located within a well-ventilated area. Inhalation of refrigerant can be hazardous to your health and the accumulation of refrigerant within an enclosed space can displace oxygen and cause suffocation.*

Installation

Receiving Inspection

Each chiller is skid mounted and boxed or crated prior to shipment. If the chiller has a remote air-cooled condenser, the chiller and the condenser will ship skid mounted and will contain a holding charge of nitrogen. Before accepting delivery, check the overall equipment condition for any visible damage and document any damage that is evident on the delivery receipt. Shipping damage is the responsibility of the carrier. In order to expedite payment for damages, it is important to follow proper procedures and record keeping. Photographs of damaged equipment are excellent documentation for your records.

Inspect for hidden damage after removing the packing. Refrigerant lines can be susceptible to damage in transit. Check for broken lines, oil leaks, damaged controls, or any other major component torn loose from its mounting point.

Our Customer Service Department will provide assistance in preparation and filing of your claims, including arranging for an estimate and quotation on repairs; however, filing the claim is the responsibility of the receiving party.

Rigging, Handling, and Locating Equipment

The units have either a formed sheet metal enclosure or a welded tube steel frame. Use proper rigging methods to prevent damage to components. Avoid impact loading caused by sudden jerking when lifting or lowering the chiller. Use pads on any abrasive surface contact areas. The frame supporting the unit is for positioning the unit with a crane or a forklift. Please refer to the drawings provided with the chiller for chiller rigging details. If the chiller has a remote air-cooled condenser, please refer to the Remote Condenser Installation Guidelines manual for further instructions on locating and rigging the remote condenser. This separate document has been prepared to assist refrigeration contractors with the installation and piping design for our remote condensers.

Standard units are for indoor use and should not be installed or even stored in an outdoor location; however, some custom units are for outdoor installations. The unit can be stored in environments between -4°F (-20°C) and 140°F (60°C) and is designed for operation in environments between 60°F (16°C) and 110°F (43°C).



CAUTION: *To prevent damage to the equipment caused by freezing, do not store or operate the unit in an ambient which may cause freezing without adequate freeze protection*

Serviceability was a primary concern when designing your portable chiller. Do not compromise this feature by locating the chiller in an inaccessible area. Please allow a minimum of three feet around the perimeter of the chiller for required clearance around the chiller. Make sure that access to the electrical enclosure is unobstructed. For air-cooled chillers, cooling performance may be limited if airflow in or out of the chiller is restricted. If it is necessary to store the chiller in an unheated area when not in use, drain all water from the unit or add an adequate amount of antifreeze to prevent freeze-up of the unit.

Foundation

Provide a rigid mounting surface for the chiller of adequate strength to support the operating weight of the chiller. It is imperative to include the entire operating weight, including the completed piping and full operating weight of the refrigerant and water, in total operating weight support requirements. The chiller once mounted should be level within a ¼" over the length and width of the unit.

Electrical Power

All wiring must comply with local codes and the National Electric Code. Minimum Circuit Ampacities (MCA) and other unit electrical data are on the unit serial tag. A specific electrical schematic is shipped with the unit. Measure each leg of the main power supply voltage at the main power source. Voltage must be within the voltage utilization range given on the chiller's nameplate. If the measured voltage on any leg is not within the specified range, notify the supplier and correct before operating the unit. Voltage imbalance must not exceed two percent. Excessive voltage imbalance between the phases of a three-phase system can cause motors to overheat and eventually fail.

Voltage imbalance is determined using the following calculations:

$$\% \text{ Imbalance} = (V_{\text{avg}} - V_x) \times 100 / V_{\text{avg}}$$

$$V_{\text{avg}} = (V_1 + V_2 + V_3) / 3$$

V_x = phase with greatest difference from V_{avg}

For example, if the three measured voltages were 198, 207, and 204 volts, the average would be:

$$(198 + 207 + 204) / 3 = 203$$

The percentage of imbalance is then:

$$(203 - 198) \times 100 / 203 = 2.46 \%$$

This exceeds the maximum allowable voltage imbalance of 2%.

The unit includes a terminal block for main power connection to the main power source. The main power source should be connected to the terminal block through an appropriate disconnect switch. A separate lug for grounding the unit is in the main control panel. Check the electrical phase sequence at installation and prior to start-up. Operation of the compressor with incorrect electrical phase sequencing will result in mechanical damage to the compressors. Check the phasing with a phase sequence meter prior to applying power. The proper sequence should read ABC on the meter. If the meter reads CBA, open the main power disconnect and switch two line leads on the line power terminal blocks (or the unit mounted disconnect). All components are wired and phased correctly at the factory. Do not interchange any load leads that are from the unit contactors or the motor terminals.



WARNING: *It is imperative that L1-L2-L3 are connected in the A-B-C phase sequence to prevent equipment damage due to reverse rotation.*



CAUTION: *The unit requires the main power to remain connected during off-hours to energize the compressor's crankcase heater. Disconnect main power only when servicing the chiller. The crankcase heater should remain on when the compressor is off to ensure liquid refrigerant does not accumulate in the compressor crankcase.*



WARNING: *The control panel is constructed such that connecting the appropriate power source to the main terminal block energizes the entire electric circuitry of the chiller. A control transformer and power supply has been factory wired to step down the incoming power to the 115VAC and 24VDC control power. Electric power at the main disconnect must be shut off before opening access panels for repair or maintenance in order to prevent exposure to energized components. Ground the unit properly in compliance with local and national codes.*

Condenser Water Lines (NQW Models Only)

The performance of a condenser is dependent on maintaining the proper flow and temperature of water through the heat exchanger. Insufficient water flow or high condenser water supply temperature will result in the reduction of cooling capacity of the chiller. Extreme conditions will eventually result in the chiller shutting down due to high refrigerant pressure. If condenser

fouling by contaminants in the condenser water stream occurs, performance is negatively affected. In order to reduce maintenance costs and chiller downtime, a water treatment program is highly recommended for the condenser cooling water. If condenser plugging occurs, contact our Customer Service Department for assistance in the proper procedure for cleaning out the condenser.



Caution: *The use of untreated or improperly treated water in a chiller can result in scaling, erosion, algae, or slime buildup. This can lead to poor system performance or premature failure.*

The standard cooling capacity assumes 85°F (29°C) condenser cooling water supply. Under normal operating conditions, there will be approximately 10°F (6°C) rise through the condenser resulting in 95°F (35°C) exiting water temperature from the condenser. To ensure proper water flow through the condenser, the condenser water pump must be able to supply the pressure drop given Figure 1 or Figure 2 when providing the required condenser water flow as shown in Table 1. While the design pressure loss is much lower than 25 PSI (1.75 Kg/cm²), we recommend the pumping system be sized for this loss to ensure there will be sufficient supply pressure to the condensers. To prevent damage to the condenser or regulating valve, the condenser water pressure should not exceed 150 PSIG (10.5 Kg/cm²). The condenser water regulating valve controls the condenser water flow. The chiller loading and condenser water inlet temperature determine the actual flow. The condenser water supply temperature range is from 70°F (21°C) to 90°F (32°C). Supply temperatures outside this range are not recommended and may lead to improper chiller operation.

The water regulating valve will modulate the flow rate of condenser water through the condenser in order to maintain the discharge pressure set point. If the discharge pressure is above the set point, the water-regulating valve will open to

Table 1 – Water Cooled Condenser Water Flow Rate Requirements

Chiller Model	Nominal Flow	
	gpm (lpm)	psid (kPA)
NQW05	16.5 (62.5)	15.4 (106.1)
NQW08	24.1 (91.2)	13.6 (93.7)
NQW10	35.8 (135.5)	29.4 (202.6)
NQW15	48 (181.7)	23.2 (159.8)
NQW20	64.9 (245.7)	11.1 (76.5)
NQW25	81.7 (309.3)	9.5 (65.5)
NQW30	96.4 (365)	18.2 (125.4)
NQW35	111.6 (422.5)	27.3 (188.1)
NQW40	124.3 (470.6)	30.6 (210.8)

increase the water flow attempting to provide more cooling. The condenser water flow can exceed nominal flow rates during these conditions and reduce the available water flow through other processes if sharing the same pump.



Warning: *If the condenser water pump is feeding other sources in addition to the chiller, it is highly recommended to install an appropriate balance valve in line with the chiller in order to limit the maximum flow through the chiller.*

Figure 1 – Condenser Water Pressure Drop Curves (NQW05 through NQW15)





Figure 2 – Condenser Water Pressure Drop Curves (NQW20 through NQW40)



Air-Cooled Chillers Condenser Air

This section only applies to air-cooled chillers. In order to accommodate the air-cooled condenser, the chiller must be located in a well-ventilated area. A minimum of three feet of clearance is required at both the condenser air inlet and condenser air discharge. Improper clearance or poor ventilation will reduce the cooling capacity of the chiller and may cause high refrigerant pressure problems. The condenser air inlet temperature must be above 60°F (15°C) in order to avoid possible low refrigerant pressure safety trips during start-up.

The performance of an air-cooled condenser is dependent upon maintaining the proper flow of air across the heat exchanger surface. If the airflow is restricted at either the intake or discharge, the cooling capacity of the chiller is reduced. Reduced airflow may also result in high refrigerant pressure problems that may cause the chiller to shut down. Airflow can also be reduced if the condenser air inlet filters become clogged with dirt. Cleaning these filters should be part of the routine maintenance program for this chiller. The frequency of required cleaning depends on the environment in which the chiller operates. The standard rated cooling capacity of this chiller is based upon 95°F (35°C) ambient air temperature. If the air temperature entering the condenser is above 95°F (35°C), the capacity will be reduced approximately 1% per 1°F (0.5°C). Entering air temperature above 110°F (43°C) may result in high refrigerant pressure problems that would shut the unit down. For this reason, it is very important that the chiller be located where the warm discharge air does not circulate back into the condenser inlet. These chillers are for indoor usage with normal indoor ambient air temperature entering the condenser. Air temperatures below 60°F (15°C) entering the condenser may result in low refrigerant pressure cold start-up problems.

Chilled Water Lines


To prevent unwanted condensation, insulate all chilled water piping. If water vapor condenses on the piping, the state change of the water from gas to liquid will result in a substantial heat load that becomes an additional burden for the chiller.

Standard portable chillers provide 50°F (10°C) coolant to the process. Under normal operating conditions there will be a 10°F (6°C) rise through the process resulting in 60°F (16°C) return coolant temperature to the chiller.

The importance of properly sized piping between the chiller and process cannot be overemphasized. See the ASHRAE Handbook or other suitable design guide for proper pipe sizing. In general, run full size piping out to the process and then reduce the pipe size to match the connections on the process equipment. Poorly designed piping is one of the most common causes of unsatisfactory chiller performance. Avoid unnecessarily long lengths of hoses or quick disconnect fittings that offer high resistance to water flow. When manifolds are required for water distribution, install them as close to the use point as possible. Provide flow balancing valves at each chilled water use point to assure adequate water distribution in the entire system. The connection labeled “Chilled Water Supply” delivers fluid to the process and the connection labeled “Chilled Water Return” receives water back from the process. Typically,

when piping is overhead with a total run length over 90 feet (27 M) there should be a valve in the supply line and an inverted P trap with a vacuum break valve installed as shown in Figure 3.

Figure 3 – Recommended Overhead Piping



Figures 4 through 9 provide the pressure drop through the evaporator and chilled water piping associated with the chiller. Use this information for assistance when sizing a chilled water pump. Nominal chilled water flow rates are provided in Table 2 and are based on a 10°F (18°C) range across the evaporator at 50°F (10°C) LWT and 85°F (29.4°C) entering condenser water. Pump curves for typical optional pumps with 60 Hz power are shown in Figure 10 – NQ Series Pump Curves.

The minimum flow rates are required to prevent fouling and to ensure the chiller stays within normal refrigerant operating conditions.

If the process flow requirement is lower than the minimum flow limitation shown in Table 2, multiple smaller chillers may be used. Another alternative is to use a primary pumping loop designed for lower flow at a higher temperature rise through the process and a secondary pumping loop designed for a higher flow and lower temperature drop through the chiller. If a secondary pumping loop is used, maintain the mixed temperature of coolant entering the evaporator at a minimum of at least 5°F (2.8°C) above the set point of the chiller.

The maximum flow limitation shown in Table 2 is the theoretical limits of the chiller based upon a 5°F (2.8°C) drop across the chiller; however, these flows result in impractical pressure drops through the chiller and are therefore not likely for a system design. If the process flow requirement is higher than the maximum flow limitation, a bypass around the chiller may be used. Another alternative is to use a primary pumping loop designed for higher flow and lower temperature rise through the process and a secondary pumping loop designed for lower flow and higher temperature drop through the chiller. If a secondary pumping loop is used, maintain the mixed temperature of coolant entering the chiller at a minimum of at least 5°F (2.8°C) above the set point of the chiller.

The use of varying chiller flows is sometimes necessary; however, it is highly recommended to use a dedicated evaporator circulation pump to provide increased system stability. The controls of the chiller are very adaptable and are capable of adjusting to variations in the flow of water through the system and will load and unload compressor(s) as needed to maintain tight control of the leaving water temperature of the system. If the chiller flow is varied, the minimum fluid loop volume must be in excess of 3 gallons of coolant per ton of cooling (3.2 L per kW) and the flow rate must change at a rate of no greater than 10% per minute in order to maintain an

acceptable level of temperature control. This is a practical amount of water which typically buffers fluctuations in the process enough that the chiller will generally see fairly gradual rates of change in the inlet water temperature and will be able to accurately load or unload the compressor(s) which in turn will allow for very consistent and stable supply temperatures to the process. Use a system volume of 6 to 10 gallons of coolant per ton (6.4 to 10.8 L per kW) if the flow rate changes more rapidly than 10% per minute. If the chiller sees a net rates of change greater than 10% per minute it may result in temporary supply temperature fluctuations greater than 1°F (0.5°C).



WARNING: Chilled water maintenance is extremely important to ensure optimal chiller performance and reliable operation. The pH of your water system is critical to the performance of your new chiller. A pH of 7.4 should be maintained and at no times should the pH be below 7.0 or above 8.0. Should this happen, possible catastrophic failure of the chiller system could occur leading to significant repair costs which are not covered under warranty.

Table 2 – Chiller Flow Rate Limitations

Chiller Model	Minimum Flow		Nominal Flow		Maximum Flow	
	gpm (lpm)	psi (kPA)	gpm (lpm)	psi (kPA)	gpm (lpm)	psi (kPA)
NQA04 & NQR04	4.9 (18.5)	1.5 (10.2)	9.7 (36.7)	5.8 (40)	19.6 (74.2)	23.8 (163.8)
NQA05 & NQR05	5.9 (22.1)	1.9 (13)	11 (41.6)	6.6 (45.5)	23.4 (88.6)	29.7 (204.4)
NQA08 & NQR08	8.6 (32.4)	1.6 (11.2)	16.8 (63.6)	6.2 (42.7)	34.2 (129.4)	25.7 (176.9)
NQA10 & NQR10	12.8 (48.4)	2.7 (18.3)	24 (90.8)	9.3 (64.1)	51.2 (193.8)	42.4 (292.4)
NQA13	14.7 (55.6)	2.4 (16.5)	26.7 (101.1)	7.9 (54.5)	58.8 (222.6)	38.4 (264.4)
NQA15 & NQR15	17.3 (65.5)	2.1 (14.7)	32.1 (121.5)	7.4 (51)	69.2 (261.9)	34.2 (235.9)
NQA20 & NQ20	23 (87.1)	2.5 (17)	43.4 (164.3)	8.8 (60.7)	92 (348.2)	39.5 (272.5)
NQA25 & NQR25	29.2 (110.4)	1.9 (13.3)	54.5 (206.3)	6.7 (46.2)	116.6 (441.5)	30.8 (212)
NQA30 & NQR30	34.6 (130.8)	2.2 (15.4)	64.3 (243.4)	7.7 (53.1)	138.2 (523.2)	35.7 (245.7)
NQR35	40 (151.2)	1.9 (13)	94.5 (357.7)	10.6 (73.1)	159.8 (605)	30.2 (208.2)
NQR40	45.4 (171.7)	2 (14.1)	104.8 (396.7)	10.9 (75.2)	181.4 (686.8)	32.6 (225)
NQW05	6.4 (24)	2.2 (15.3)	12.7 (48.1)	8.7 (60)	25.4 (96.1)	35 (240.8)
NQW08	9.2 (34.8)	1.9 (12.8)	18.5 (70)	7.5 (51.7)	36.8 (139.3)	29.7 (204.8)
NQW10	14 (53)	3.2 (21.9)	27.6 (104.5)	12.3 (84.8)	56 (212)	50.8 (349.8)
NQW15	18.7 (70.8)	2.5 (17.2)	36.9 (139.7)	9.7 (66.9)	74.8 (283.1)	40 (275.6)
NQW20	25 (94.6)	2.9 (20.1)	50.3 (190.4)	11.8 (81.4)	100 (378.5)	46.7 (321.9)
NQW25	31.5 (119.2)	2.2 (15.5)	62.8 (237.7)	8.9 (61.4)	126 (476.9)	35.9 (247.5)
NQW30	37.2 (140.8)	2.6 (17.8)	74.3 (281.3)	10.3 (71)	148.8 (563.2)	41.3 (284.8)
NQW35	42.7 (161.6)	2.2 (14.9)	86.3 (326.7)	8.8 (60.7)	170.8 (646.5)	34.5 (237.9)
NQW40	47.6 (180.2)	2.2 (15.5)	95.8 (362.6)	9.1 (62.7)	190.4 (720.7)	36 (247.8)

Figure 4 – Standard Flow Unit Coolant Pressure Drop Curve (NQ4 and NQ5)




Figure 5 – High Flow Unit Coolant Pressure Drop Curve (NQ04 and NQ05)




Figure 6 – Standard Flow Unit Coolant Pressure Drop Curve (NQ8 through NQ15)




Figure 7 – High Flow Unit Coolant Pressure Drop Curve (NQ08 through NQ15)




Figure 8 – Standard Flow Unit Coolant Pressure Drop Curve (NQ20 through NQ40)




Figure 9 – High Flow Unit Coolant Pressure Drop Curves (NQ20 through NQ40)





Figure 10 – NQ Series Pump Curves



System Fluid Freeze Protection

For applications where system fluid will be exposed to ambient conditions of 32°F (0°C) or colder and/or the set point of the system will be below 45°F (7.2°C), antifreeze must be added to the system fluid to protect the chiller and system piping from potential damage. The amount of antifreeze will vary depending on the actual desired operating conditions and should be enough to provide freeze protection to temperatures 15°F (8.3°C) colder than the coldest temperature anticipated. Use only antifreeze solutions designed for heat exchanger duty. Do not use automotive antifreeze due to the potential for fouling that can occur once its relatively short-lived inhibitors break down.

Interconnecting Refrigerant Piping (NQR Models Only)

The chiller is shipped with a nitrogen holding charge and has a full charge of oil, excluding the additional charge for field piping. Proper evacuation is required prior to charging with refrigerant. The chiller is for use only with the air-cooled condenser provided with the unit. The following section covers the required piping between the chiller and the provided air-cooled condenser.

Caps are located on the discharge and liquid lines. These line sizes do not necessarily reflect the actual line sizes required for the piping between the chiller and the air-cooled condenser. The installing contractor need only provide the interconnecting piping between the chiller and the air-cooled condenser.

Refrigerant piping size and piping design has a significant effect on system performance and reliability. For specific pipe sizing and configuration, refer to the NQR Series Chiller Remote Air-Cooled Condenser Installation Guidelines Manual. All piping should conform to the applicable local and state codes. Use refrigerant grade copper tubing only and isolate the refrigeration lines from building structures to prevent transfer of vibration. Do not use a saw to remove end caps. This might allow copper chips to contaminate the system. Use a tube cutter or heat to remove the caps. When sweating copper joints it is important to flow dry nitrogen through the system. This prevents scale formation. Do not use soft solders. For copper-to-copper joints use a phos-copper solder with 6% to 8% silver content. Use a high silver content brazing rod for copper-to-brass or copper-to-steel joints. Only use oxy-acetylene brazing.

Operating Principles

Coolant Circuit

The coolant pump, external to the chiller, circulates coolant through the process piping and then back to the chiller. Upon entering the chiller, the coolant will pass through a Y-Strainer that filters the process fluid before entering the evaporator. Heat transferred from the coolant to the refrigerant occurs in the evaporator. Varying the amount of heat transferred in the evaporator determines the loading of the compressor, which maintains the temperature set point of the coolant delivered to the process. A “Process Return” temperature sensor senses the temperature of the coolant as it enters the evaporator.

After leaving the evaporator, the coolant passes by a flow switch and the “Process Supply” temperature sensor. The sensor senses the temperature of the coolant delivered to process and communicates this temperature to the PLC controller. This sensor is the control sensor for the PLC control system.

Refrigerant Circuit

The heat transferred in the evaporator from the coolant to the refrigerant changes the state of the refrigerant from a liquid to a gas. This refrigerant gas then moves from the evaporator to the compressor.

The compressor is the heart of the refrigeration circuit. Cool, low-pressure gas enters the compressor and hot, high-pressure gas exits the compressor. Since the compressor is not 100% efficient, some extra heat gain occurs as the refrigerant is compressed.

The hot, high-pressure gas exiting the compressor goes to the condenser. In water-cooled condenser units (NQW models), the heat is transferred from the refrigerant flow around the tubes to the water that is flowing through the tubes. In air-cooled condenser units (NQA & NQR models), the heat is transferred from the refrigerant in the finned tubes to the air that is flowing across the finned tubes. As the heat transfer occurs, the refrigerant changes from a gas to a liquid. The condenser removes the heat from the process load and the heat that is added by the compressor.

After leaving the condenser, the liquid refrigerant passes through the filter dryer and sight glass. The filter dryer filters out any particles and/or moisture from the refrigerant. Use the sight glass to monitor the stream of liquid refrigerant. The liquid refrigerant then passes through the thermostatic expansion valve, which meters the flow into the evaporator where the process begins again.

Capacity control is achieved by redirecting some of the hot gas from the compressor outlet away from the condenser. This gas is metered through an electronically controlled, stepper motor driven Hot Gas Bypass Valve. The hot gas is injected into the evaporator inlet, reducing the chiller’s cooling capacity during light loading. The Hot Gas Bypass Valve is opened by the PLC when the supply water temperature is below the Temperature Set Point.

Start-Up

Every unit is factory set to deliver chilled water in accordance with the standard operating specifications for that particular chiller. Due to variables involved with different applications and different installations, minor adjustments may be required during the initial start-up to ensure proper operation. The following startup procedure should be followed in sequence. If trouble is encountered during start-up, the fault can usually be traced to one of the control or safety devices. This outline can be used as a checklist for the initial start-up and for subsequent start-ups if the chiller is taken out of service for a prolonged period of time.

1. Assure the main power source is connected properly, that it matches the voltage shown on the nameplate of the unit, and that it is within the voltage utilization range given in the Electrical Power Section of this manual. Electrical phase sequence must be checked at installation and prior to start-up. Operation of the compressor with incorrect electrical phase sequencing will result in mechanical damage to the compressors. The phasing must be checked with a phase sequence meter prior to applying power. The proper sequence should read “ABC” on the meter. If the meter reads “CBA”, open the main power disconnect and switch two line leads on the line power terminal blocks (or the unit mounted disconnect). All components requiring electric power are wired in-phase at the factory. Do not interchange any load leads that are from the unit contactors or the motor terminals. Once proper power connection and grounding have been confirmed, turn the main power on.



WARNING: *It is imperative that L1-L2-L3 are connected in the A-B-C phase sequence to prevent equipment damage due to reverse rotation.*

Note: *The main power must be on for 24 hours prior to starting the compressor to allow the crankcase heater to sufficiently vaporize any liquid refrigerant that may be present in the compressor.*

2. Check to make sure that all process chilled water piping connections are secure. Open the cabinet and fill the chilled water reservoir with the proper water or water/glycol solution. Use glycol with a corrosion inhibitor only. See Table 3 for recommended glycol solutions. 25% glycol is recommended even if running at temperatures higher than 25°F to help protect the evaporator from potential freezing.
3. (NQW Models Only) Check the condenser water lines to make sure all connections are secure. Make sure sufficient condenser water flow and pressure are available, the condenser water supply is turned on, and all shut-off valves are opened
4. (NQR Models Only) Check the refrigerant lines to make sure all connections are secure and that a proper evacuation of the chiller, the field piping, and the remote condenser has occurred.

5. Charge the chiller with refrigerant. For NQR chillers, please refer to the NQR Series Chiller Remote Air-Cooled Condenser Installation Guidelines Manual to determine the required refrigerant charge. NQA and NQW chillers come factory charged and should require no additional refrigerant.

6. (NQR Models Only) Check the remote condenser main power and control wiring to ensure all connections are secure.

7. Verify that all refrigerant valves are open.

8. Make sure the Freezestat is set appropriately for the operating conditions of the chiller. The Freezestat setting is in a password protected menu of the chiller controller. Refer to the Controller Operation Section for instruction on how to access this menu, It should be set at 10°F (5°C) below the minimum chilled water temperature setting that the chiller will be operating. Reference Table 3 to be sure the coolant solution has sufficient freeze protection (glycol) to handle at least 5°F (2.8°C) below the Freezestat setting. All chillers are shipped from the factory with the Freezestat set at 38°F (3°C). This is done to protect against a possible freeze-up if no glycol has been added to the coolant. Once the proper glycol solution has been added, the Freezestat can be adjusted to the appropriate setting.

Table 3 - Recommended Glycol Solutions

Chilled Water Temperature	Percent Glycol By Volume
50°F (10°C)	Not required
45°F (7.2°C)	5 %
40°F (4.4°C)	10 %
35°F (1.7°C)	15 %
30°F (-1.1°C)	20 %
25°F (-3.9°C)	25 %
20°F (-6.7°C)	30 %
15°F (-9.4°C)	35 %
10°F (-12.2°C)	35 %
5°F (-15°C)	40 %
0°F (-17.8°C)	40 %

Note: The manufacturer's warranty does not cover the evaporator from freezing. It is vital that the Freezestat is set properly.

9. Turn on the control power by turning the control power switch to "On". The panel displays should now be illuminated.

10. Due to extreme ambient temperatures that the unit may be exposed to during shipment, the High Refrigerant Pressure switch may have tripped. If this is the case, disconnect the main power and reset the High Refrigerant Pressure by depressing the manual reset button located on the switch. Reconnect the main power and turn the control power on by pressing the Power button. Clear the alarm condition by pressing the Alarm Reset button.

11. Establish flow through the evaporator. Standard units are provided with an internal pump that can be energized by pressing the Start button. If the unit has been customized and does not have an internal pump, the external pump should be energized to establish flow through the evaporator.

Note: The compressor will not start as long as the flow switch is open. A positive flow must be established through the evaporator before the compressor can operate.

12. Set water flow through the evaporator as indicated in Table 1 using a discharge throttling valve or flow control valve (by others). The valve should be the same size as the To Process connection of the chiller. A significant increase in flow beyond the recommended rate may damage the evaporator and create excessive pressure drops that influence the overall efficiency of the system.
13. Set the desired leaving water temperature on the control panel. The chiller should now be controlling to the selected temperature. Please note that if there is insufficient load the compressor may cycle on and off causing swings in temperature.



WARNING: Under no circumstance should the High Refrigerant Pressure or the Low Compressor Pressure switch be deactivated. Failure to heed this warning can cause serious compressor damage, severe personal injury or death.

14. Regulation of the chiller temperature is based on supply water temperature. Unless otherwise specified, it is factory set to deliver coolant at 50°F (10°C). Adjust to the desired operating temperature. Resetting the temperature will change the operating conditions of the chiller. Any lower readjustment of the controller must be done only after referencing Table 3 to ensure that the coolant has adequate antifreeze protection.
15. Operate the system for approximately 30 minutes. Check the liquid line sight glass. The refrigerant flow past the sight glass should be clear. Bubbles in the refrigerant indicate either low refrigerant charge or excessive pressure drop in the liquid line. A shortage of refrigerant is indicated if operating pressures are low and subcooling is low. Normal subcooling ranges are from 10°F (5.5°C) to 20°F (11°C). If subcooling is not within this range, check the superheat and adjust if required. The superheat should be approximately 10°F (5.5°C). Since the unit is factory charged, adding or removing refrigerant charge should not be necessary. If the operating pressures, sight glass, superheat, and subcooling readings indicate a refrigerant shortage, charge refrigerant as required. With the unit running, add refrigerant vapor by connecting the charging line to the suction service valve and charging through the backseat port until operating conditions become normal.



CAUTION: A clear sight glass alone does not mean that the system is properly charged. Also check system superheat, subcooling, and unit operating pressures. If both suction and discharge pressures are low but subcooling is normal, a problem other than refrigerant shortage exists. Do not add refrigerant, as this may result in overcharging the circuit.

Once proper flow and temperature are achieved, press the Stop button. The unit is now ready to be placed into service.

Microprocessor Controller Operation



The chiller includes a microprocessor controller to perform all control functions directly from the front panel. When Control Power is applied, the controller initiates a diagnostic test of each indicating light and display segment which momentarily lights them sequentially. As part of this initial diagnostic test, the program revision level display in the temperature display for a moment. After the initial diagnostic sequence is completed, the controller is ready for operation.



Start Button

Depressing the Start button will start the pump and enable the compressor. The compressor (and condenser fans if the chiller is air cooled) will start only if the microprocessor is calling for cooling because the actual To Process temperature is higher than the Set Point temperature. If the Autostart feature is enabled, the Autostart signal will have precedence over the Start Button. See the Program Menu section for instructions on how to enable or disable the Autostart feature.

The Start button also performs an “Enter” function while in the programming menu.



Stop Button

Depressing the Stop button will shut off the compressor, pump, condenser fans (if the chiller is air cooled), and clear all fault signals. If the Autostart feature is enabled and there is an Autostart signal present, the Stop button will not stop the chiller. See the Program Menu section for instructions on how to enable or disable the Autostart feature.

This button also performs a “Cancel” function while in the programming menu.



Alarm Silence / Alarm Reset Button

When an alarm condition is present, the alarm LED above the Alarm Silence/Reset button will be on and red. The first Alarm Silence/Reset button press will silence the alarm horn (optional), open the remote alarm contact (optional), and the LED toggles from red to yellow. The alarm horn and/or remote alarm contact remain disabled until a subsequent alarm occurs. A second press of the Alarm Silence/Reset button resets the state from Alarm to Normal Operation.

The High Refrigerant Pressure and Pump Overload require a mechanical safety to be manually reset before the control board can be reset. If the fault is still present the unit will immediately go into a new alarm state.



Compressor Running Hours Button

Press and hold the Compressor Running Hours Button to display the amount of time that each compressor in the system has been enabled. The Set Point window will show which compressor’s usage is being displayed (for units with two compressors). The running hours will be shown in the process display window. Display of running hours is in units of hundreds so a display value of 10 would mean 1,000 hours. The running hours will be displayed for as long as the button is held. For units with two compressors, the display will toggle between the two compressors every three seconds. The hours will be displayed for as long as the button is held. Control is not disturbed while the hours are being displayed.



Pump Running Hours Button

Press and hold the Pump Running Hours Button to display the amount of time that the pump has been enabled. The running hours will be shown in the process display window. Display of running hours is in units of hundreds so a display value of 10 would mean 1,000 hours. The running hours will be displayed for as long as the button is held. The hours will be displayed for as long as the button is held. Control is not disturbed while the hours are being displayed.



Pump Test Button

While the chiller is stopped, this button may be used to briefly engage the pump to test its operation. The pump will not run if there are any active alarms. The pump may be shut down by either pressing the Stop button or pressing the Pump Test button a second time. If no action is taken, the pump will shut down after one minute of operation.



Display/Program Button

The Display/Program button will change the temperature displayed in the Process screen from Supply to Return. When the display is set to supply temperature, there will be an orange indicating light in the lower right corner of the Process temperature display. When the display is set to return temperature, there will be no orange indicating light in the lower right corner of the Process temperature display. To toggle the process temperature display from supply to return temperature, press and release the Display/Program button. The display will return to the default Supply temperature automatically after 5 seconds without a button press.

In addition to switching between the supply and return process temperature displays, the Display/Program button will initiate and navigate through the program menu. See the Program Menu section for more detail.



Up Button

The Up Arrow button raises the set point temperature. Pressing the Up Arrow and releasing it increases the set point temperature by one degree. Pressing the Up Arrow button and holding it increases the set point temperature until reaching the maximum allowable set point temperature. In addition to adjusting the set point temperature, the Up Arrow button adjusts various alarms and set point values when the unit is the programming mode.



Down Button

The Down Arrow button decreases the set point temperature. Pressing the Down Arrow and releasing it decreases the set point temperature by one degree. Pressing the Down Arrow button and holding it decreases the set point temperature until reaching the minimum allowable set point temperature. In addition to adjusting the set point temperature, the Down Arrow button adjusts various alarms and set point values when the unit is in the programming mode.



Control Power On LED

The Control Power light is on and green when the Control Power Switch is in the ON position and 24VDC control voltage is present.



Autostart Signal LED

The Autostart Signal light is on and yellow when the Autostart function is enabled and no Autostart signal is present. It is on and green when the Autostart function is enabled and the signal is present. This feature allows the unit to be turned on and off by a remote contact closure. Switching the contacts from open to close simulates pressing the Start button on the control panel. Switching the contacts from closed to open simulates pressing the Stop button. From the factory, the Autostart feature is disabled. See the Program Menu section for instructions on how to enable or disable the Autostart feature.



Warning: Do not introduce any external voltage to these contacts, as this will result in damage to the microprocessor.



Pump LED

The Pump LED is solid green while in normal running operation. It will flash red if the overload safety trips.



Hot Gas Bypass LED

The Hot Gas Bypass LED will pulse or be illuminated solidly when the chiller is operating at partial load. Under partial load, the hot gas bypass valve is opened in order for the chiller to maintain a constant To Process temperature. The hot gas bypass valve opens to a variable percentage. The LED indicates an approximate opening percentage by pulsing for varying amounts of time. If the LED is illuminated for 5 seconds, that means that the valve is open 50%, while if it is opened for 10 seconds, it is open 100%. The longer that this LED stays on, the more unused excess capacity is available from the chiller. If the Partial Load LED stays off, the chiller

is fully loaded by the heat from the process. If the Partial Load LED stays on, the chiller has a very small load on it from the process. If this low load condition persists, the To Process temperature may begin to drop below the Set Point temperature, eventually cycling off compressor(s).



Compressor #1 LED

The Compressor #1 LED is solid green while Compressor #1 is running. It will flash red if a compressor overload condition exists (only chillers with the following nominal tonnages: 15, 25, 30, 35, 40). Compressor #1 will be enabled whenever the temperature of water leaving the chiller rises above the Set Point by an amount equal to the control parameter PS1 (Compressor #1 Positive Spread). PS1 is equal to 2 °F by default. The compressor will be disabled if the temperature of water leaving the chiller drops below the Set Point by an amount equal to the control parameter nS1 (Compressor #1 Negative Spread). The parameter nS1 is set to 4 °F by default. See the Program Menu section for instructions on how to adjust PS1 and nS1. To prevent excessive compressor cycling, the control board has a compressor anti-cycle delay timer built in. Any time that a compressor is being prevented from turning on by the anti-cycle timer, the Compressor Recycle LED will be lit.



Compressor #2 LED

The Compressor #2 LED is solid green while Compressor #2 is running. Compressor #2 is only present on chillers 20 tons and larger. It will flash red if a compressor overload condition exists (only chillers with the following nominal tonnages: 15, 25, 30, 35, and 40). Compressor #2 will be enabled whenever the temperature of water leaving the chiller rises above the Set Point by an amount equal to the control parameter PS2 (Compressor #2 Positive Spread). PS2 is equal to 3 °F by default. The compressor will be disabled if the temperature of water leaving the chiller drops below the Set Point by an amount equal to the control parameter nS2 (Compressor #2 Negative Spread). The parameter nS2 is set to 5 °F by default. See the Program Menu section for instructions on how to adjust PS2 and nS2. To prevent excessive compressor cycling, the control board has a compressor anti-cycle delay timer built in. Any time that a compressor is being prevented from turning on by the anti-cycle timer, the Compressor Recycle LED will be lit.



Temperature Limit LED

The Temperature Limit LED will flash yellow if a deviation warning exists. It will flash red if a high or low critical temperature safety alarm condition exists.



Electrical Phase Error LED

The Electrical Phase Error LED flashes red when a line voltage problem exists. This error indicates a loss of phase, phase reversal, or phase imbalance.



Low Flow LED

The No Flow LED will be illuminated if the flow through the chiller is below the preset acceptable level. When the Start button is depressed, this safety is defeated for a period of 5 seconds in order for the pump to establish flow. This safety will shut off the pump and the compressor. If the chiller has been shut down by the No Flow safety, the Start button must be depressed in order to restart the pump and reset the 5 second time delay.



Freezestat LED

If the coolant temperature being delivered to the process drops below the Freezestat Limit (FLS) setting, the compressor will shut off, the pump will remain running, and the Freezestat LED will be illuminated. The Freezestat Limit should be set 10°F (5°C) above the freezing point of the glycol solution and 10°F (5°C) below the minimum operating temperature. The Freezestat is factory set at 38°F (3°C). In order to reset the Freezestat fault press the Alarm Reset button after the temperature has risen 5°F (3°C) above the Freezestat Limit. See the Program Menu section for instructions on how to adjust FLS.



Low Reservoir Level LED

When the water level in the reservoir drops below the lower limit of the float switch, the Low Water Level LED is illuminated and the pump will shut off.



Compressor Recycle LED

The number of compressor startups per hour is limited in order to maximize compressor lifetime and ensure proper return of oil to the compressor crankcase. This light is illuminated yellow whenever there is a wait period before the compressor can be started.



High Refrigerant Pressure LED

If the compressor discharge refrigerant pressure exceeds the setting on the high refrigerant pressure safety, the compressor and pump will shut off and the High Refrigerant Pressure LED will be illuminated. Pressing the Alarm Reset button will reset the High Refrigerant Pressure fault, as long as the High Refrigerant Pressure switch located at the discharge of the compressor has been manually reset.



Low Refrigerant Pressure LED

If the compressor suction pressure drops below the setting on the low refrigerant pressure safety, the compressor will shut off, the pump will remain running, and the Low Refrigerant Pressure LED will be illuminated. Pressing the Alarm Reset button will reset the Low Refrigerant Pressure fault, as long as the refrigerant pressure has risen back up above the safety's cutout level.



Program Mode LED

The Program Mode LED will flash yellow while in the programming menu.

Set Point Temperature Display

The Set Point Temperature Display normally displays the set point temperature. An indicator light in the lower right corner of this display area shows the temperature unit of measure that has been set in the programming menu. When the display is set to °F there will be a green indication light, when the display is set to °C there will be no green indicating light. See the Program Menu section to change the temperature scale units of measure.

In addition to displaying the set point temperature, the Set Point temperature display shows other alarm and programming information.

Process Temperature Display

The Process Temperature Display displays the selected supply or return temperature. An indicator light in the lower right corner of the display area show the temperature displayed. When the display is set to supply temperature there will be an orange indicating light, when the display is displaying return temperature there will be no orange indicating light. To toggle the Process temperature display from supply to return temperature, press and release the Display/Program button. The display will return to the default Supply temperature automatically after 5 seconds without a button press. The display will return to the default Supply Temperature automatically after 5 seconds. In addition to displaying the selected temperature, the display shows other alarm and programming information.

Program Menu

The program menu provides access to a number of control user-adjustable parameters and feature enable/disable control. Access the program menu is password protected to prevent unintended alteration to the program settings and parameters.

To access the programming menu the unit must be in a stopped state. Once the unit is stopped, press and holding the Display/Program button for 5 continuous seconds. The Program Mode LED will flash yellow and the display will show "PAS" on the Process display and "000" on the Set Point display. The unit is now ready to have the password entered. From the factory, the password is set to "000". Use the Up or Down arrow buttons to increase the numeric value on

the Set Point display until the correct password value is shown. To enter the password, press and release the Start button.

If the password is entered incorrectly, there will be a "no" on the Set Point display and "PAS" on the Process display. After 5 seconds, the unit will go back to the password entry mode and display "PAS" on the Process display and "blanks" on the Set Point display. If no activity occurs for another 5 seconds, the controller exits the programming mode and returns to the Stopped state.

Once in the program menu, use the Display/Program button to scroll through the different adjustable parameter as shown in Table 4 below. To change an item, press the Display/Program button until the item code displays in the Process display. Pressing the Alarm Reset button and Display/Program button at the same time will reverse the direction the Display/Program button indexes through the menu items. Once the desired menu item code displays in the Process display, use the Up and Down arrow buttons to adjust the value shown in the Set Point display until the desired value is shown. Press the Start button to enter the display value. Press the Stop button to cancel and revert to the previously value.

There is a Master Reset function to restore all User menu parameters to their factory default values. To initiate a Master Reset the unit must be in a stopped state. Once the unit is stopped, press and hold the Alarm Silence/Reset button and Stop button simultaneously for 10 consecutive seconds until "PRG" is displayed on the Set Point display and "RSt" is displayed on the Process display. To confirm a Master Reset is desired, press and release the Start button and the system will perform a Master Reset and reboot. The Master Reset is aborted after the "PRG" is displayed on the Set Point display and "RSt" is displayed on the Process display by turn the control power off or taking no action for 10 consecutive seconds.

Table 4 - Controller Program Menu

Item Name	Item Code	Default Value	Range
Alarm Delay - High Deviation	AdH	30	10 to 60
Alarm Delay - Low Deviation	AdL	30	10 to 60
Autostart Enabled	ASE	DIS	Disabled (DIS) or Enabled (EnA)
Brownout Enabled	brn	EnA	Disabled (DIS) or Enabled (EnA)
Comm Baud Rate	bAU	96	12 to 96
Comm Modbus ID	id	1	1 to 247
Comm SPI Address	SPA	32	32 to 63
Communications Type	COt	OFF	OFF, Retransmit (rEt), SPI (SPI) or ModBus (bUS)
Compressor 1 Negative Spread	nS1	4	1 to 10
Compressor 1 Positive Spread	PS1	2	1 to 10
Compressor 2 Enabled	CO2	DIS	Disabled (DIS) or Enabled (EnA)
Compressor 2 Negative Spread	nS2	5	1 to 10
Compressor 2 Positive Spread	PS2	3	1 to 10
Derivative	dEr	3	0 to 200
Display Units	Unt	F	F to C
Freezestat Limit	FSL	40	-50 to 40
High Deviation Alarm Limit	HId	10	5 to 100
Integral	Int	25	1 to 800
Low Deviation Alarm Limit	Lod	10	5 to 100
Proportional Band	bnd	8	1 to 300
Remote Setpoint High Limit	rSH	65	Between rSL and 999
Remote Setpoint Low Limit	rSL	20	Between -99 and rSH
Remote SP Enabled	rSE	DIS	Disabled (DIS) or Enabled (EnA)
Retransmit Range High	rEH	150	Between 999 and rEL
Retransmit Range Low	rEL	0	Between -99 and rEH
User High Safety Limit	HSU	140	Between factory low and high limits
User Low Safety Limit	LSU	10	Between factory low and high limits
User Password	UPA	000	0 to 999

Table 5 – Controller Control Fault Logic

Fault	Alarm Indication	Pump Shut Off	Compressor Shut Off	Alarm Reset Required ¹	Manual Reset Required ²	Remote Alarm Activated ³
Low Reservoir Level	The Reservoir Level Light flashes red	Yes	Yes	Yes	Yes	Yes
Temperature Limit Safety	The Set Point and Process Temperatures Flash and the Temperature Limit Light flashes red	Yes	Yes	Yes	No	Yes
Temperature Limit Warning	The Temperature Limit Light flashes yellow	No	No	Yes	No	Yes
Pump Motor Overload	The Pump Light flashes red	Yes	Yes	Yes	Yes	Yes
Compressor Motor Overload	The Compressor Light flashes red	No	Yes	Yes	No	Yes
High Refrigerant Pressure	The High Refrig Pressure Light flashes red	No	Yes	Yes	Yes	Yes
Low Refrigerant Pressure	The Low Refrig Pressure Light flashes red	No	Yes	Yes	No	Yes
Low Evaporator Temperature	The Freezestat Light flashes red	No	Yes	Yes	No	Yes
Supply Probe Fault Hi	The Set Point Temperature Display shows “PRS” and the Process Temperature Display shows “EHi”	Yes	Yes	Yes	No	Yes
Supply Probe Fault Lo	The Set Point Temperature Display shows “PRS” and the Process Temperature Display shows “ELo”	Yes	Yes	Yes	No	Yes
Return Probe Fault Hi	The Set Point Temperature Display shows “PRR” and the Process Temperature Display shows “EHi”	Yes	Yes	Yes	No	Yes
Return Probe Fault Lo	The Set Point Temperature Display shows “PRR” and the Process Temperature Display shows “ELo”	Yes	Yes	Yes	No	Yes
Freezestat Probe Fault Hi	The Set Point Temperature Display shows “PRF” and the Process Temperature Display shows “EHi”	Yes	Yes	Yes	No	Yes
Freezestat Probe Fault Lo	The Set Point Temperature Display shows “PRF” and the Process Temperature Display shows “ELo”	Yes	Yes	Yes	No	Yes
Brownout	The Set Point Temperature Display shows “Brn” and the Process Temperature Display shows “Out”	Yes	Yes	Yes	No	Yes
3-Phase Power Error	The Electrical Phase Error list flashes red	Yes	Yes	Yes	No	Yes
Low Flow	The Low Flow Light flashes red	Yes	Yes	No	No	Yes

¹ Alarm Silence/Reset button on control panel must be pressed.

² Safety control device must be manually reset before the controller can be reset.

³ Activates the alarm horn and closes the alarm contact if the remote alarm contact option has been purchased.

Table 6 – ModBus Option Parameters (Integer Values)

Reg	Description	Read/Write	Notes
4000	CONTROLLER BOARD TYPE	R	0x5432= F20, 0x5434 = F40
4001	SOFTWARE VERSION	R	100x version, e.g. 119 = ver 1.19
4002	MACHINE STATE	R	0 = Off, 1 = Stop, 2 = Run, 3 = Run Fault 2, 4 = Run Fault 3, 5 = Fault 1, 6 = Factory Menu, 7 = User Menu, 8 = Get User Password, 9 = Master Reset
4003	INPUT TYPE 0	R	0 = RTD2, 1 = RTD3, 2 = RTD PWC, 4 = 0-1V, 5=TC
4004	INPUT TYPE 1	R	0 = RTD2, 1 = RTD3, 2 = RTD PWC, 4 = 0-1V, 5=TC
4005	INPUT TYPE 2	R	0 = RTD2, 1 = RTD3, 2 = RTD PWC, 4 = 0-1V, 5=TC
4006	INPUT TYPE 3	R	0 = RTD2, 1 = RTD3, 2 = RTD PWC, 4 = 0-1V, 5=TC
4007	DERIVATIVE	R/W	
4008	INTEGRAL	R/W	
4009	HEAT CYCLE RATE	R	
4010	COOL CYCLE RATE	R	
4011	LOW ALARM DELAY	R	
4012	HI ALARM DELAY	R	
4013	DISPLAY UNITS	R	0 = Deg F, 1 = Deg C
4014	CONTROLLER TYPE	R	0 = TCU, 1 = Chiller
4015	BROWNOUT ENABLED	R	0 = DISABLED, 1 = ENABLED
4016	AUTOTUNE ENABLED	R	0 = DISABLED, 1 = ENABLED
4017	SEAL SAVER ENABLED	R	0 = DISABLED, 1 = ENABLED
4018	REM HEAT COOL ENABLED	R	0 = DISABLED, 1 = ENABLED
4019	PURGE ENABLED	R	0 = DISABLED, 1 = ENABLED
4020	CRASH COOL ENABLED	R	0 = DISABLED, 1 = ENABLED
4021	FLOW ENABLED	R	0 = DISABLED, 1 = ENABLED
4022	NOT USED	X	
4023	NOT USED	X	
4024	REM SETPOINT ENABLED	R	0 = DISABLED, 1 = ENABLED
4025	AUTOSTART ENABLED	R	0 = DISABLED, 1 = ENABLED
4026	NOT USED	X	
4027	COMM BAUD RATE	R/W	0 = 1200, 1 = 2400, 2 = 4800, 3 = 9600
4028	MODBUS ID	R/W	
4029	CURRENTLY CONTROLLING	R	0 = NO, 1 = YES
4030	SPI ADDR	R/W	
4031	MODICON FLOAT FORMAT	R	0 = NO, 1 = YES
4032	COMM TYPE	R/W	0 = NONE, 1 = MODBUS, 2 = SPI, 3 = PV REXMIT, 4 = HAND HELD DISPLAY
4033	COMP 2 ENABLED	R	0 = DISABLED, 1 = ENABLED
4034	HEAT COOL SWITCH DELAY	R	
4035	DAC OUTPUT SPI0	R	16 bit value being sent to DAC card
4036	DAC OUTPUT SPI1	R	16 bit value being sent to DAC card
4037	DAC OUTPUT COMM	R	16 bit value being sent to DAC card
4038	PID OUT	R	-100 to 100 PID algorithm output
4039	MODBUS COMMAND	R/W	0 = Do Nothing, 1 = Start, 2 = Stop
4040	EXTENDED RANGE ENABLED	R	0 = DISABLED, 1 = ENABLED

ModBus Parity = None, Stop Bits = 1

Table 7 – ModBus Option Parameters (Floating Point Values)

Reg	Description	Read/Write	Notes
8000	FREEZESTAT TEMPERATURE READING (°C)	R	Error Hi = 9.9E05, Error Low = -9.9E05
8002	SUPPLY WATER TEMPERATURE (°C)	R	Error Hi = 9.9E05, Error Low = -9.9E05
8004	RETURN WATER TEMPERATURE (°C)	R	Error Hi = 9.9E05, Error Low = -9.9E05
8006	N/A	R	Error Hi = 9.9E05, Error Low = -9.9E05
8008	N/A	R	
8010	LOW DEVIATION (°C)	R/W	
8012	HI DEVIATION (°C)	R/W	
8014	LOW SETPOINT LIMIT (°C)	R	
8016	HI SETPOINT LIMIT (°C)	R	
8018	REXMIT RANGE LOW (°C)	R	
8020	REXMIT RANGE HI (°C)	R	
8022	LOW SAFETY TEMP USER (°C)	R/W	
8024	HI SAFETY TEMP USER (°C)	R/W	
8026	PROPORTIONAL BAND (°C)	R/W	
8028	NOT USED	X	
8030	ZERO CAL CHAN 0	R	
8032	ZERO CAL CHAN 1	R	
8034	ZERO CAL CHAN 2	R	
8036	ZERO CAL CHAN 3	R	
8038	SPAN CAL CHAN 0	R	
8040	SPAN CAL CHAN 1	R	
8042	SPAN CAL CHAN 2	R	
8044	SPAN CAL CHAN 3	R	
8046	NOT USED	X	
8048	NOT USED	X	
8050	NOT USED	X	
8052	PUMP RUN HOURS	R	
8054	SETPOINT (°C)	R/W	
8056	LOW SAFETY TEMP FACTORY (°C)	R	
8058	HI SAFETY TEMP FACTORY (°C)	R	
8060	NEG COMP 1 SPREAD (°C)	R	
8062	NEG COMP 2 SPREAD (°C)	R	
8064	POS COMP 1 SPREAD (°C)	R	
8066	POS COMP 2 SPREAD (°C)	R	
8068	FREEZESTAT LIMIT (°C)	R	
8070	SUPPLY TEMP INPUT OFFSET	R	
8072	RETURN TEMP INPUT OFFSET	R	
8074	REMOTE SP INPUT OFFSET	R	
8076	FLOW INPUT OFFSET	R	
8078	FREEZESTAT INPUT OFFSET	R	

Note: All temperatures are in °C regardless of unit display configuration.

Continued on next page

Figure 7 – ModBus Option Parameters (Floating Point Values) - continued

Reg	Description	Read/Write	Notes
8080	REM SETPOINT LOW (°C)	R	
8082	REM SETPOINT HI (°C)	R	
8084	ZERO CAL LINEAR CHAN 0	R	
8086	ZERO CAL LINEAR CHAN 1	R	
8088	ZERO CAL LINEAR CHAN 2	R	
8090	ZERO CAL LINEAR CHAN 3	R	
8092	SPAN CAL LINEAR CHAN 0	R	
8094	SPAN CAL LINEAR CHAN 1	R	
8096	SPAN CAL LINEAR CHAN 2	R	
8098	SPAN CAL LINEAR CHAN 3	R	
8100	CJC ZERO CAL	R	
8102	TC SPAN CAL CHAN 0	R	
8104	TC SPAN CAL CHAN 1	R	
8106	TC SPAN CAL CHAN 2	R	
8108	TC SPAN CAL CHAN 3	R	
8110	COMP 1 RUN HOURS	R	
8112	COMP 2 RUN HOURS	R	

Note: All temperatures are in °C regardless of unit display configuration.

PLC Controller Navigation


Start-Up Screen & Contact Information

This is the first screen to be displayed after the chiller's control circuit is turned on. One may also reach this screen from the Active Alarms Screen / Alarm History by pressing the "TC Contact Info" button.

1. Go to Main Screen: press anywhere on the display once.

Main Screen


On this screen, the user has On/Off control of the chiller. The user may change the temperature set points of the chiller.



1. Local/ Remote Start Mode (Press to Toggle)
 - a. *If "Local" is shown:* Chiller is started and stopped from this touch screen.
 - b. *If "Remote" is shown:* Chiller is started and stopped by remote contacts.
2. Chiller Start - Pressing this button will start the chiller if "Local Control" is ON.
 - a. *If "Start" is shown:* Chiller is OFF
 - b. *If "Running" is shown:* Chiller is ON
3. Chiller Stop - Pressing this button will stop the chiller if "Local Control" is ON.
 - a. *If "Stopped" is shown:* Chiller is OFF
 - b. *If "Stop" is shown:* Chiller is ON
4. Temperature Set Point Display & Entry: To change the set point, press the set point display. This will bring up a numeric keypad screen. Use the keypad to enter your desired temperature and press "ENT" to confirm or "ESC" to cancel.
5. Actual Supply Water Temperature Display: The measured supply temperature of water going to the process is displayed.
6. Go to Refrigeration Diagnostic Screen: Change to screen that displays diagnostic information for the refrigeration system. From this screen, one can also access the status of the chiller programmable controller's inputs and outputs.
7. Go To Process Diagnostic Screen: Change to screen that displays diagnostic information for the process.
8. Go to Compressor Setup screen: *You will be prompted for a password to access this screen.* The compressor staging parameters can be changed from this screen. From this screen, one can access all other password protected parameters such as temperature alarm set points and temperature control tuning. (The Password is "9999".)
9. Go to Active Alarms Screen / Alarm History: This screen will display any active alarms or warnings and allow you to access troubleshooting information for any active alarm. You can also access an alarm history from this screen.
10. Alarm Notification: This will appear blank if no alarms or warnings are active. This box will be flashing if a warning or alarm is active.

Refrigeration Diagnostic Screen


On this screen, the user can see information that will help identify and troubleshoot refrigeration system issues.



1. Go to Active Alarms Screen / Alarm History screen:
 - a. This will appear blank if no alarms or warnings are active. This box will be flashing if a warning or alarm is active.
 - b. Press this button to be taken to the Active Alarms Screen / Alarm History.
2. Hot Gas Bypass Output Percentage
 - a. This is the control signal being sent to the Hot Gas Bypass Valve. Percentage corresponds to percent open. There is some lag in valve response, so it will not correspond to the exact valve location at all times.
 - b. This is a heating function and it will open to prevent the Supply Temperature from dropping below the Set Point.
 - c. It is normal for the valve to be open at some percentage at almost all times. This chiller is designed with excess cooling capacity, and this valve balances that excess capacity.
 - d. A hissing noise emitted from the Hot Gas Bypass Valve is typical when the valve is open.
 - e. If the Supply Water is constantly a few degrees under set point, the process is on, and the HGBP % is high, there may be an electrical or mechanical problem with the Hot Gas Bypass Valve. One may notice a lack of a hissing sound in this case.
3. Go to Main Screen: Pressing this button will take you back to the Main Screen.
4. Go to Compressor Setup screen: You will be prompted for a password to access this screen. The compressor staging parameters and all other password protected parameters such as temperature alarm set points and temperature control tuning can be changed from this screen. (The Password is "9999".)

5. Go to Process Diagnostic Screen: Change to screen that displays diagnostic information for the Process.
6. Go to Process Diagnostic Screen: This screen displays status of the chiller's programmable controller.
7. Compressor ON/OFF Status & Running Hours: Shows the status and running hours of the compressor(s).
8. Set Point and Supply Temperature: The Supply temperature is roughly the same temperature as the water leaving the evaporator.


Process Diagnostic Screen




1. Supply and Return Water Temperature Display
 - a. The temperature sensor for water supplied to the process is always displayed.
 - b. The temperature sensor for water returning from the process is displayed unless the Return Temperature Option is not present.
2. Go to Active Alarms Screen / Alarm History screen
 - a. This will appear blank if no alarms or warnings are active. This box will be flashing if a warning or alarm is active.
 - b. Press this button to be taken to the Active Alarms screen.
3. Pump ON/OFF Indication: Shows pump status.
4. Go to Main Screen: Pressing this button will take you back to the Main Screen.
5. Go to Compressor Setup screen: You will be prompted for a password to access this screen. The compressor staging parameters can be changed from this screen. From this screen, one can access all other password protected parameters such as temperature alarm set points and temperature control tuning. (The Password is "9999".)
6. Go to Output Status / Output Designation screen: This screen displays status of the chiller's programmable controller.
7. Hot Gas Bypass Output Percentage:

- a. This is the control signal being sent to the Hot Gas Bypass Valve. Percentage corresponds to percent open. There is some lag in valve response, so it will not correspond to the exact valve location at all times.
- b. This is a heating function and it will open to prevent the Supply Temperature from dropping below the Set Point.
- c. It is normal for the valve to be open at some percentage at almost all times. This chiller is designed with excess cooling capacity, and this valve balances that excess capacity.
- d. A hissing noise emitted from the Hot Gas Bypass Valve is typical when the valve is open.
- e. If the Supply Water is constantly a few degrees under set point, the process is on, and the HGBP % is high, there may be an electrical or mechanical problem with the Hot Gas Bypass Valve. One may notice a lack of a hissing sound in this case.

Active Alarms Screen / Alarm History






1. Alarms & Troubleshooting Tips: Press the alarm for which you want to see Troubleshooting Information. Then press the Troubleshooting Tips button to bring up the information.
2. Alarm Reset: Press this button to reset any active alarm or warning conditions. An Alarm/Warning indication will be shown again if Reset is pressed but the issue has not been resolved.
3. Go to Main Screen: takes you back to the Main Screen.
4. Go to Alarm History Screen: Takes you back to the Active Alarms Screen / Alarm History.
5. Go to Contact Information Screen: Takes you to the Contact Information Screen.
6. Alarm History Navigation/Acknowledgement: Use these buttons to scroll through the alarm history and acknowledge previous alarms. Acknowledgement here is only for optional record keeping and is not needed to resume chiller operation.
7. Go to Process Diagnostic Screen: Change to screen that displays diagnostic information for the water circuit, including the temperature of water returning from the process.
8. Go to Active Alarms Screen: Takes you to the Active Alarms Screen / Alarm History screen.






















Output Status / Output Designation

The **Output Status Screen** shows whether digital outputs from the chiller's programmable controller are ON or OFF. "0" represents OFF while "1" represents ON. Each symbol (Y0, Y1 etc) represents a physical output that is labeled both on the controller and the chiller's electrical schematic.



1. Go to Output Designation Screen: Show what devices are wired to each output. (Note that the output designations found on your unit may vary from what is shown here)
2. Go to Input Status Screen: Go to a similar screen for the controller's Input Status.
3. Go to Main Screen: Takes you back to the Main Screen.

Setup Screens (Password is "9999")

<p style="text-align: center;"><i>Compressor Setup</i></p> <table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <th colspan="2" style="text-align: left;">Compressor 1</th> <th colspan="2" style="text-align: left;">Compressor 2</th> </tr> <tr> <td>CutIn 1</td> <td>SP+ 2 °F</td> <td>CutIn 2</td> <td>SP+ 3 °F</td> </tr> <tr> <td>CutOut1</td> <td>SP- 3 °F</td> <td>CutOut2</td> <td>SP- 4 °F</td> </tr> <tr> <td>Cut Out2</td> <td>Cut Out1</td> <td>Set Point</td> <td>Cut In1</td> <td>Cut In2</td> </tr> <tr> <td></td> <td></td> <td></td> <td></td> <td></td> </tr> <tr> <td>46 °F</td> <td>47 °F</td> <td>50 °F</td> <td>52 °F</td> <td>53 °F</td> </tr> <tr> <td>Process Setup</td> <td>PID Setup</td> <td>FreezeStat Setup</td> <td>Main</td> </tr> </table> <p>Adjust the cut in and cut out points for the refrigeration compressor(s). Cut in and Cut Out values are relative to Set Point.</p>	Compressor 1		Compressor 2		CutIn 1	SP+ 2 °F	CutIn 2	SP+ 3 °F	CutOut1	SP- 3 °F	CutOut2	SP- 4 °F	Cut Out2	Cut Out1	Set Point	Cut In1	Cut In2						46 °F	47 °F	50 °F	52 °F	53 °F	Process Setup	PID Setup	FreezeStat Setup	Main	<p style="text-align: center;"><i>Temperature Alarm Settings</i></p> <table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <th colspan="4" style="text-align: center;">Water Temperature Setting</th> </tr> <tr> <th colspan="2" style="text-align: left;">Supply Water, T</th> <th colspan="2" style="text-align: left;">Return Water, T</th> </tr> <tr> <td>Hi</td> <td>120 °F</td> <td>Hi</td> <td>120 °F</td> </tr> <tr> <td>HiHi</td> <td>140 °F</td> <td>HiHi</td> <td>140 °F</td> </tr> <tr> <td>Lo</td> <td>0 °F</td> <td colspan="2" rowspan="2" style="text-align: center; border: 1px solid black;"> Hi Temp. Bypass Timer 20 Min. </td> </tr> <tr> <td>LoLo</td> <td>0 °F</td> </tr> <tr> <td><input type="checkbox"/></td> <td>HGBP PID</td> <td>Compressor Setup</td> <td>Main</td> </tr> </table> <p>Adjust the temperature alarm points. "Hi" and "Lo" designate Warning points. The system will show an amber flash if one of these points is reached, but the unit will not shut down. "HiHi and LoLo" are Critical Alarm Points. The chiller will shut down if one of these points is reached. The "Hi Temp Bypass Timer" is an adjustable timer that will bypass the temperature warnings for some time after start-up.</p>	Water Temperature Setting				Supply Water, T		Return Water, T		Hi	120 °F	Hi	120 °F	HiHi	140 °F	HiHi	140 °F	Lo	0 °F	Hi Temp. Bypass Timer 20 Min.		LoLo	0 °F	<input type="checkbox"/>	HGBP PID	Compressor Setup	Main
Compressor 1		Compressor 2																																																								
CutIn 1	SP+ 2 °F	CutIn 2	SP+ 3 °F																																																							
CutOut1	SP- 3 °F	CutOut2	SP- 4 °F																																																							
Cut Out2	Cut Out1	Set Point	Cut In1	Cut In2																																																						
																																																										
46 °F	47 °F	50 °F	52 °F	53 °F																																																						
Process Setup	PID Setup	FreezeStat Setup	Main																																																							
Water Temperature Setting																																																										
Supply Water, T		Return Water, T																																																								
Hi	120 °F	Hi	120 °F																																																							
HiHi	140 °F	HiHi	140 °F																																																							
Lo	0 °F	Hi Temp. Bypass Timer 20 Min.																																																								
LoLo	0 °F																																																									
<input type="checkbox"/>	HGBP PID	Compressor Setup	Main																																																							
<p style="text-align: center;"><i>Freezestat Setup</i></p> <table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <th colspan="2" style="text-align: center;">FreezeStat</th> </tr> <tr> <td>Set Point</td> <td>36 °F</td> </tr> <tr> <td>CutIn</td> <td>3 °F</td> </tr> <tr> <td>Set Point</td> <td>Cut In</td> </tr> <tr> <td></td> <td></td> </tr> <tr> <td>36 °F</td> <td>39 °F</td> </tr> <tr> <td><input type="checkbox"/></td> <td>HGBP PID</td> <td>Compressor Setup</td> <td>Main</td> </tr> </table> <p>Set the Freezestat to the chilled water temperature shown for your glycol solution concentration per Table 3. The chiller will have a critical Freezestat alarm if the</p>	FreezeStat		Set Point	36 °F	CutIn	3 °F	Set Point	Cut In			36 °F	39 °F	<input type="checkbox"/>	HGBP PID	Compressor Setup	Main	<p style="text-align: center;"><i>Hot Gas Bypass PID</i></p> <table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <th colspan="2" style="text-align: center;">Hot Gas Bypass PID Tuning</th> </tr> <tr> <td>Proportional Gain, Kp</td> <td>850</td> </tr> <tr> <td>Integral Time, Ti</td> <td>250</td> </tr> <tr> <td>Derivative Time, Td</td> <td>5</td> </tr> <tr> <td>Refrigeration Diagnostic</td> <td>Compressor Setup</td> <td>Main</td> </tr> </table> <p>If the chiller seems to function normally but has difficulty maintaining set point, consult Customer Service for assistance with PID Tuning.</p>	Hot Gas Bypass PID Tuning		Proportional Gain, Kp	850	Integral Time, Ti	250	Derivative Time, Td	5	Refrigeration Diagnostic	Compressor Setup	Main																														
FreezeStat																																																										
Set Point	36 °F																																																									
CutIn	3 °F																																																									
Set Point	Cut In																																																									
																																																										
36 °F	39 °F																																																									
<input type="checkbox"/>	HGBP PID	Compressor Setup	Main																																																							
Hot Gas Bypass PID Tuning																																																										
Proportional Gain, Kp	850																																																									
Integral Time, Ti	250																																																									
Derivative Time, Td	5																																																									
Refrigeration Diagnostic	Compressor Setup	Main																																																								

Freezestat sensor detects water at this Set Point. The system may not be restarted until the water reaches the Set Point + the Cut-in value.	
--	--

Components

Chilled Water Return Temperature Sensor

The temperature sensor is in the return fluid piping and senses the temperature of the chilled water entering the evaporator. The chilled water in temperature is on the HMI screen. This probe is directly in the fluid stream, there is not a sensor well included.

Chilled Water Supply Temperature Sensor

This temperature sensor is in the chiller reservoir and it transmits the chilled water supply temperature to the PLC. The reading from this sensor is used as the control variable for the chiller's temperature control. The reading is compared to the set point and the hot gas bypass valve is positioned to drive the temperature reading towards the set point. The Hot Gas Bypass Valve is opened towards 100% when the temperature is below set point, and is closed towards 0% when the temperature is above set point. This probe is directly in the reservoir, there is not a sensor well included.

Compressor

The chiller is equipped with a hermetic scroll compressor. Both the compressor and the motor are encased together and solidly mounted in the cabinet. The compressor is unidirectional and will only pump refrigerant when properly phased. The cool refrigerant suction gas cools the motor windings, and there is an internal thermal overload to protect the windings from overheating. The compressor is lubricated with oil that travels throughout the system with the refrigerant. Chillers with capacities of 20 tons or more are equipped with two compressors in tandem. The compressors are able to be operated independently if the heat load is not large enough to require both compressors.

Compressor Electronic Motor Module

The compressor is fitted with an electronic protection device located within the compressor motor terminal box. This device monitors the temperature of the motor with a series of PTC sensors mounted in the motor winding, the discharge gas and oil temperature via the oil temperature sensor, motor rotation, and phase failure. At the trip-point temperature, the compressor shuts down immediately. If an incorrect phase rotation or phase failure occurs within the first five seconds after start-up, the compressor will also shut down immediately. If repeated phase failures occur or any other fault listed above occurs, the module locks out and requires a manual reset. The main power must be off for at least five seconds to reset the module. If a temperature fault occurred, the compressor must also first cool down before the module will reset.

Condenser Remote Air-Cooled (NQR Models Only)

The remote air-cooled condenser has a copper tube and aluminum fin coil with multiple fans. The refrigerant passes through the copper tubes, while the air passes over the fins. The condenser supplied is equipped to vary the header fan(s) speed and operate the remaining fans as needed to control the refrigerant discharge pressure under varying ambient and chiller loading conditions. Please see the NR Series Chiller Remote Air-Cooled Condenser Installation Guidelines Manual for proper mounting and connection of the condenser.

Condenser Integrated Air-Cooled (NQA Models Only)

The condenser is constructed of aluminum micro-channel maximum heat transfer capabilities. The condenser has been generously sized so the chiller can operate with full cooling capacities in ambient air temperatures of up to 95°F (35°C). The chiller should be able to operate with ambient temperatures of up to 110°F (43°C). The fans draw cool air through the condensers and discharges warm air out the top of the cabinet. Units equipped with condenser fans are designed to draw sufficient air through the chiller as long as there are no obstructions. The fans are not designed to draw air through ductwork or discharge air through ductwork, though some models may be able to have their exhaust ducted. Consult Customer Service. The discharge air will be approximately 35°F (20°C) warmer than the intake air.

Fan Cycling Controls (NQA Models Only)

The fan cycling controls are designed to turn one condenser fan on and off in order to maintain a minimum compressor discharge refrigerant pressure. During normal operation, the fan or blower will cycle on and off based upon the process heat load and ambient air conditions.

Condenser Water-Cooled (NQW Models Only)

The shell and tube condenser is a steel shell, removable cast iron end bells, and a bundle of copper tubes. The condenser water passes through the copper tubes, while the refrigerant flows around the tubes on the shell side. A water maintenance program should be in place to preserve the quality of water used to cool the condenser. Excessive condenser fouling caused by poor water quality will cause poor chiller performance and or chiller failure.

Condenser Water Regulating Valve (NQW Models Only)

A condenser water regulating valve is provided as standard on all NQW chillers. This valve is located in the condenser water piping at the outlet of the condenser. It regulates the flow of water through the condenser in order to maintain the high-pressure side of the refrigeration circuit. This valve is set at the factory and should only be adjusted by a qualified refrigeration technician. The valve only passes as much water as is required to maintain the refrigerant pressure, so less water will be required if the water temperature is lower than the design 85°F (29°C).

Note: The condenser water regulating valve may not completely shut-off water flow when the chiller is not operating. If flow must be completely stopped for any reason, a shut-off valve (manufactured by others) must be used. Make sure the shut-off valve is reopened before restarting the chiller.

Coolant Flow Switch

This switch is located in the piping directly before the evaporator inlet. It shuts the unit down if there is insufficient coolant flow through the evaporator. The switch is not adjustable. If the chiller shuts down due to low coolant flow, restart using the HMI on the control panel.

Crankcase Heater

The compressor crankcase heater prevents too high of refrigerant concentration in the oil during shut down. It is mounted around the outer shell of the compressor and is replaceable if necessary without accessing the refrigeration circuit.

Evaporator

The evaporator has stainless steel plates and copper brazing. The refrigerant passes between every other set of plates, while the coolant flows on the other side of the plates in the opposite direction. We recommend implementing a proper water maintenance program to preserve the quality of chilled water desired. Excessive evaporator fouling caused by poor chilled water quality will cause poor chiller performance and or chiller failure.

Hot Gas Bypass Valve

This valve is located in the refrigerant line that runs from the compressor discharge to the evaporator inlet. It is designed to artificially load the chiller when the chiller is not fully loaded by the process. This is accomplished by directing some of the hot compressor discharge gas directly back into the evaporator instead of going through the condenser. The microprocessor controller controls the amount of hot gas used. Eliminating cycling of the compressor is extremely desirable as it significantly extends its lifetime expectancy.

High Refrigerant Pressure Switch

The high refrigerant pressure switch limits the compressor discharge pressure so that it stays within the design parameters of the compressor. The switch is located on the compressor discharge line. It is set to open at 575 PSIG (3964 kPa) on NQA and NQR chillers, and 540 PSIG (3723 kPa) on NQW chillers. This switch has a manual reset.

Should the switch open when a fault condition occurs, pressing the reset button on the back of the switch and pressing the alarm reset button on the control panel will reset the alarm. The setting on the switch is not adjustable.

Low Refrigerant Pressure Switch

The low refrigerant pressure switch is designed to limit the compressor suction pressure to within the designed parameters of the compressor. The switch is located in the suction side of the compressor and can be reset by pressing the alarm reset button on the control panel. The setting on this switch is set to cut out at 40 PSIG (275 kPa) and cut in at 95 PSIG (655 kPa).

Human Machine Interface (HMI)

The human machine interface (HMI) provides a user interface with the PLC, which controls the operation of the chiller. The HMI allows data entry for chiller setup, accepts commands to operate chiller, and displays chiller status.

Pressure Relief Valve

A pressure relief valve is installed on all pressure vessels to safely relieve pressure due to fire or other abnormal operating conditions. NQW chillers have a pressure relief valve installed on the water-cooled condenser, NQA chillers have one on the liquid line, and NQR chillers have one installed on the receiver. Replace this valve if it opens.

Note: Vent refrigerant relief valves in accordance to ANSI/ASHRAE Standard 15, Safety Code for Mechanical Refrigeration.

Receiver

The receiver is standard on NQR units and optional on NQA and NQW units. It is primarily a liquid storage tank to hold liquid refrigerant when not in circulation. Since an air-cooled condenser located outdoors provides the refrigeration cycle cooling, the refrigerant charge will vary from winter to summer operation. During the summer months, the receiver holds the excess refrigerant charge required in the winter. The receiver also aids in holding the refrigerant charge while in pump down.

Refrigerant Filter/Drier

The filter/drier is located in the liquid line after the condenser. It removes any moisture and/or foreign matter that may have gotten into the refrigerant stream. Moisture and foreign matter can cause serious damage to the components of a refrigeration system. For this reason, it is important that the chiller be equipped with a clean filter/drier. Replace the filter/drier core if any of the following conditions occur.

- Opening the refrigeration system to the atmosphere for repairs or maintenance
- Indication of moisture in the sight glass
- An excessive pressure drop develops across the filter/drier (A significant temperature difference between the filter inlet and outlet indicates this.)

Refrigerant Service Valve

A manual two-way ball valve is provided in the refrigerant liquid line just downstream of the condenser or receiver.

Refrigerant Sight Glass

The refrigerant sight glass is located on the liquid line. It allows the operator or service technician to observe the flow of liquid refrigerant in the circuit. Prolonged periods of foaming in the sight glass may indicate a low refrigerant condition or a restriction in the liquid line.

Note: Occasional bubbling in a sight glass may occur at a time when load conditions are changing and the expansion valve is adjusting to the new conditions. This momentary occurrence is a result of normal chiller operation.

Another use for the sight glass is check if there is moisture in the refrigeration circuit.

Y-Strainer

A Y-Strainer with a 20-mesh screen is in the entering chilled water line to help protect the evaporator passages from clogging.

Automatic Water Make-Up (Optional)

With this option, a water supply can be connected to the chiller so that the water level in the reservoir is automatically maintained. When the water level in the reservoir drops below the low level on the float switch, a solenoid valve will be opened to allow fresh water into the system. When the water level reaches the high level on the float switch, the solenoid valve is closed.

Note: This option is not normally recommended for systems that depend on a glycol solution to prevent freeze-ups. Automatic water make-up may cause reduction of the glycol concentration, which may result in an evaporator freeze-up.

Coolant Pump

The close-coupled centrifugal pump is equipped with a mechanical seal and is constructed of stainless steel. The pump is factory tested for the specified operating conditions. The pump motor meets NEMA specifications and industry standards.

Upgraded Pumps (Optional)

The standard pumps that have been selected for each size chiller will meet the requirements of most applications; however, in certain instances, larger pumps may be required to provide the desired flow and pressure for a specific application. The horsepower of the pump will be indicated on the chiller nameplate.

Pressure Gauge

A pressure gauge is mounted on the back panel of the chiller. This gauge displays the pressure of the coolant at the discharge of the pump. It can be used to determine the approximate point on the pump curve in which the pump is operating.

Reservoir

The reservoir is mounted inside the cabinet. The reservoir is made of polyethylene and is fully insulated. A level sight tube is included so the coolant level can be observed. There is a removable cover on the top of the reservoir. During chiller operation the reservoir should be at least half full. For most installations the reservoir has sufficient capacity to handle coolant drain back from the process equipment which occurs during chiller shut down. For installations with overhead piping runs of over 90 feet, (27 M) special precautions will have to be made during installation (see Figure 3).

Preventive Maintenance

Once your portable chiller has been placed into service, the following maintenance procedures should be adhered to as closely as possible. The importance of a properly established preventive maintenance program cannot be overemphasized. Taking the time to follow these simple procedures will result in substantially reduced downtime, reduced repair costs, and an extended useful lifetime for the chiller. Any monetary costs of implementing these procedures will almost always more than pay for it.

To make this as simple as possible, a checklist should be prepared which lists the recommended service operations and the times at which they are to be performed. At the end of this section we have included a checklist that can be used for this purpose. Notice that there are locations for voltage readings, amperages, etc. so that they can be monitored over time. With this information, maintenance personnel may be able to correct a potential problem before it causes any downtime. For best results, these readings should be taken with a full heat load from process, preferably with similar operating conditions each time. The following is a list of suggested periodic maintenance.

Once a Week

1. (Air-Cooled Units Only) Check the surface of the air-cooled condenser coil for dirt and debris. To clean, rinse thoroughly with water. Mild detergent can be used to remove smoke and or grease stains.
2. Check to make sure that the To Process temperature is maintained reasonably close to the Set Point temperature. If the temperature stays more than 5°F (3°C) away from the set point, there may be a problem with the chiller. If this is the case, refer to the Troubleshooting Chart or contact the Customer Service Department.
3. Check the pump discharge pressure on the gauge on the back panel of the chiller. Investigate further if the pressure starts to stray away from the normal operating pressure.
4. Check the coolant level in the reservoir. Replenish if necessary making sure to take proper precautions to maintain the appropriate glycol concentration.
5. Check coolant circulation pump for leaks in the seal area. Replace pump seal if necessary.
6. Check refrigerant sight glass for air bubbles or moisture indication. If the sight glass indicates that there is a refrigeration problem, have the unit serviced as soon as possible.

Once a Month

7. With the main disconnect shut off and locked out, check the condition of electrical connections at all contactors, starters and controls. Check for loose or frayed wires.
8. Check the incoming voltage to make sure it is within 10% of the design voltage for the chiller.
9. Check the amp draws to each leg of the compressor (fans or blowers on air-cooled units) and pump to confirm that they are drawing the proper current.

Every Three Months

10. Units are equipped with a Y-strainer between the return connection and the evaporator inlet. The strainer basket should be removed and cleaned if necessary. This may be required more often if contaminants can easily get into the process water.
11. Have a qualified refrigeration technician inspect the operation of the entire unit to ensure that everything is operating properly. Have condenser cleaned out if necessary.

Preventive Maintenance Checklist

Maintenance Activity	Week Number												
	1	2	3	4	5	6	7	8	9	10	11	12	13
Date													
Clean Condenser Coil and Inlet Filter (air cooled units)													
Temperature Control													
Pump Discharge Pressure													
Coolant Level													
Glycol Concentration													
Pump Seal													
Refrigerant Sight Glass													
Electrical Connections													
Incoming Voltage													
Compressor #1 L1 Amps													
Compressor #1 L2 Amps													
Compressor #1 L3 Amps													
Compressor #2 L1 Amps													
Compressor #2 L2 Amps													
Compressor #2 L3 Amps													
Pump L1 Amps													
Pump L2 Amps													
Pump L3 Amps													
Fan #1 L1 Amps													
Fan #1 L1 Amps													
Fan #1 L3 Amps													
Fan #2 L1 Amps													
Fan #2 L2 Amps													
Fan #2 L3 Amps													
Fan #3 L1 Amps													
Fan #3 L2 Amps													
Fan #3 L3 Amps													
Clean Y-Strainer													
Refrigerant Circuit Check													
Refrigerant Suction Pressure													
Refrigerant Discharge Pressure													
Refrigerant Superheat													

Troubleshooting

Problem	Possible Cause	Remedy
Compressor will not start	Compressor overload	Check supply voltage, amperage of each leg, contactor and wiring, and overload set point
	Compressor contactor	Replace if faulty
	Compressor failure	Contact Customer Service for assistance
Pump will not start	Pump overload	Check supply voltage, amperage of each leg, contactor and wiring, and overload set point
	Pump contactor	Replace if faulty
	Pump failure	Replace if faulty
Low refrigerant pressure	Low refrigerant charge	Contact refrigeration service technician
	Refrigerant leak	Contact refrigeration service technician
	Low refrigeration pressure sensor	Check for proper range, replace if faulty
High refrigerant pressure	Dirty air filters (air-cooled units only)	Clean filters
	Air flow obstruction (air-cooled units only)	Make sure chiller is installed in accordance with recommendations in this manual
	High ambient air temperature (air-cooled units only)	Ambient temperature must be reduced below 110°F (43°C)
	Condenser fan motor (air-cooled units only)	Replace if faulty
	Condenser fan cycling control (air-cooled units only)	Confirm proper operation, replace if faulty
	Plugged condenser (water-cooled units only)	Clean out tubes
	Insufficient condenser water flow (water-cooled units only)	Make sure chiller is installed in accordance with the recommendations of this manual
	High condenser water temperature (water-cooled units only)	Condenser water temperature must be reduced below 100°F (38°C)
	Condenser water regulating valve	Check setting, replace if faulty
	Refrigerant circuit overcharged	Contact refrigeration service technician
	High refrigerant pressure sensor	Replace if faulty
Freezestat	Low flow through evaporator	Adjust flow to proper level
	Freezestat control module	Check for proper setting (Protected Setting)
	Freezestat sensor	Replace if faulty
Low pump discharge pressure	Pump running backwards	Switch 2 legs of the incoming power
	Pump pressure gauge	Replace if faulty
	Pump failure	Replace if faulty
	Excessive flow	Reduce flow
High pump discharge pressure	Closed valves in process piping	Open valves
	Obstruction in piping or process	Remove obstruction
	Clogged Y-strainer	Clean strainer
	Pressure gauge	Replace if faulty

Problem	Possible Cause	Remedy
Erratic temperature control	Low coolant flow through evaporator	Adjust flow to proper level
	Intermittent overloading of chiller capacity	Check to make sure chiller is properly sized for process load
	Hot gas bypass valve	Contact refrigeration service technician
	Temperature sensor	Replace if faulty
Insufficient cooling (temperature continues to rise above set point)	Process load too high	Check to make sure chiller is properly sized for process load
	Coolant flow through evaporator too high or low	Adjust flow to proper level
	Insufficient condenser cooling	See "High Refrigerant Pressure"
	Hot gas bypass valve stuck open	Contact refrigeration service technician
	Refrigeration circuit problem	Contact refrigeration service technician
	Temperature sensor	Replace if faulty

Drawings

We have prepared a custom set of drawings for your unit and placed them inside the control panel prior to shipment. Please refer to these drawings when troubleshooting, servicing, and installing the unit. If you cannot find these drawings or wish to have additional copies, please contact our Customer Service Department and reference the serial number of your unit.

Notes

Notes



www.imscompany.com | phone order toll-free (USA & Canada) **1 800 537 5375**

fax order toll-free (USA & Canada) **1 888 288 6900**

phone order toll-free (Mexico) **001 888 304 1307**

tech support toll-free (USA & Canada) **1 866 467 9001**

e-mail

sales@imscompany.com

