

10373 Stafford Road Chagrin Falls, OH 44023–5296
Tel: 440.543.1615 Fax: 440.543.1069
Toll-Free Tel (USA & Canada): 800.537.5375
Toll-Free Tel (Mexico): 001.888.304.1307
Toll-Free Fax (USA & Canada): 888.288.6900

Tech-Support Hot Line Toll-Free Tel (USA & Canada): 866.467.9001

Online Catalog: www.imscompany.com

E-mail: sales@imscompany.com



40 WATT CARTRIDGE HEATERS IMS #165818

To fit (#109470) 7½" and (#109466) 8¼" HEATED GATE CUTTERS

SOLD IN PAIRS WITH PLUG AND 6' CONTAMINATION-RESISTANT LEADS COATED WITH PTFE

November, 2016 IMS Company 10373 Stafford Road

Chagrin Falls, OH 44023-5296

Telephone: (440) 543-1615

Fax: (440) 543-1069

Email: sales@imscompany.com
Website: imscompany.com

©2016 IMS Co.



ASSEMBLY

REMOVE EXISTING CARTRIDGE HEATER

Unplug controller.

Disconnect wires from controller.

Remove tape securing wires to handles.

Remove top retaining clip on each heater.

Slide heaters off blades.

Remove bottom retainer clip on each heater.

Slide heaters through handle cushions.

DANGER

Contact with ELECTRIC POWER will cause DEATH OR SHOCK.

Make sure cutters are grounded through controller.

Unplug controller to service cutters.

Do not allow wires to rub against each other or against other parts of cutter.

INSTALL NEW CARTRIDGE HEATERS.

Make sure controller is unplugged and old heater wires are removed.

Remove retainer clips from heaters

Slide heaters through handle cushions. You might need to work the wire channel a little with your fingers to open it up for the heaters. NEVER PULL heaters. Continue to PUSH leads to get them through wire channels.

Slide heaters into blades as shown in Figure on the next page.

Install bottom retainer clip on each heater. This is easiest if you slide clip over open end of heater first.

Apply heat transfer compound to heaters. IMS Infra-Kote (#107264 – 2 oz or #103781 – 16 oz) works well.

Slide heaters into blades as shown in Figure on the next page.

Install top retaining clip on each heater.

Tapes wires to handle. Leave a little slack in wires. Leave a small gap between wires to keep them from rubbing against each other.

With controller unplugged, connect wires to controller.



ASSEMBLY (continued)

